



N° Perches	cadre de scène	N° -1
------------	----------------	-------

2	-1535	530
1	-1005	1430
1	425	
2	535	110
3	625	90
4	725	100
5	825	100
6	935	110
7	1195	260
8	1470	275
9	1820	350
10	2040	220
11	2330	290
12	2505	175
13	2680	175
14	2855	175
15	3030	175
16	3205	160
17	3405	200
18	3595	190
19	3750	155
20	3925	175
21	4110	185
22	4575	465
23	4755	100
24	4920	165
25	5110	190
26	5300	190
27	5465	165
28	5645	180
29	5820	175
30	6005	185
31	6190	180
32	6370	180
33	6550	180
34	6725	175
35	6905	180
36	7405	500
37	7905	500
38	8220	315
39	8570	350